

SOLITEX EXTASANA® ADHERO Application Guide



Pro Clima Australia Pty Ltd
PO Box 924
Gosford
NSW 2250
Phone: 1800 PRO CLIMA (1800 776 254)
Email: welcome@proclima.com.au
www.proclima.com.au

Pro Clima New Zealand Ltd
PO Box 925
CBD
Wellington 6140
Phone: 0800 PRO CLIMA (0800 776 254)
Email: welcome@proclima.co.nz
www.proclima.co.nz



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommendations given or to make alterations to our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

HORIZONTAL INSTALLATION




Remove 150mm release paper and adhere to substrate on a pre-marked height.



Remove second release paper, smooth down from centre of sheet working outward. Use PRESSFIX-XL. Overlap minimum 150mm as per markings. Must extend over the bottom plate by minimum 35mm.

Cut membrane at opening




SOLITEX EXTASANA ADHERO to be cut at 45° to corners of openings.

Seal membrane at opening



Apply TESCON EXTOSEAL sill tape to wall openings as per NZBC Acceptable Solution E2/AS1 paragraph 9.1.5.b.

Sealing pipe penetrations



Use pro clima ROFLEX and TESCON EXTORA to seal pipe penetrations.

VERTICAL INSTALLATION



Remove both release papers and adhere from top down following a pre-marked vertical line.



Overlap by min 150mm at vertical joints, smoothing down underlay evenly across the sheet width using PRESSFIX-XL. Must extend over the bottom plate by minimum 35 mm.

Fold membrane into opening




SOLITEX EXTASANA ADHERO to be folded into opening and adhered to framing.

Foil tape: wet-seal applications



For wet-seal applications please refer to the the TISCON ADHISO WS Application Guide.

Sealing cable penetrations



Use pro clima KAFLEX to seal cable penetrations.